



## Legend

### Where the Water Flows & Goes

- Beard Ditch
- Hopper Creek
- ➔ General Direction of Flow
- Water Flow from North to South of Town

### Storm Drain Lines

— STORM-DRAIN

● Town Pump Station

In general, storm water flows from the north of town to the south of town via our gutters and storm drain systems. Portions of the storm drain system drain via pipe to Beard Ditch. The flood project created flood prevention measures including

1. Flood weirs at Three Weirs Park
2. Designated flood water overflow down Oak Circle to Beard Ditch
3. Flood wall at Rancho de Napa and Bella Vista neighborhoods.

The water in Beard Ditch eventually makes its way into Hopper Creek and then into the Napa River.